



MAP EXPLANATION



PROFILE STATIONING (in thousands of feet) 15 X



FLOOD HAZARD ZONE DATA (NOTED ON MAP IN RED)

ZONE A: Special flood hazard areas inundated by the 100-year flood, determined by approximate methods; no base flood elevations or Flood Hazard Factors determined.

ZONES A1 To A20: Special flood hazard areas inundated by the 100-year flood, with base flood elevations determined and zone designations assigned according to the Flood Hazard Factor.

ZONE B: Areas of additional hazard between the 100-year and 500-year flood.

ZONE C: Areas of minimal flooding.



BASE FLOOD ELEVATION LINE (elevation in feet) 995

CONTOUR INTERVALS 10 FEET

MAP SCALE NOTED AT BASE OF INDIVIDUAL FLOODMAPS